



## CARTRIDGE RECORDER TAPE HEADS

CONFIDENTIAL REPLACEMENT HEAD CONVERSION LIST

MODEL #	Mfr. Head No.	Head Function	Mount Type	Relacement Part Numbers		
				Original Head	Duracore	No Mount Conversion
<b>AMPRO (Instatape)</b>		NOTES: Play-only machines have no record head. Use 7605 for dummy record head.				
CT-2500, 3500, 4500, 5500 Series Mono	9086-1 9103-1	Record Program & Cue Play Program & Cue	No Mount	2010 2001	2010D 2001D	
CT-2500, 3500, 4500, 5500 Series Stereo	9085-1 9102-1	Record Program & Cue Play Program & Cue	No Mount	5710 5701	— 5701D	
<b>ATC (Gates)</b> (See also Harris)		NOTES: Play-only machines have no record head. Use 7605 for dummy record head. * Conversion to No Mount heads not recommended.				
Criterion CP11, CP112, CP13 Mono	20-1014 20-1011	Record Program & Cue Play Program & Cue	Rear Mount	2053 2057	2053 2057D	• •
Criterion CP11, CP12, CP13 Stereo	20-1016 20-1015	Record Program & Cue Play Program & Cue	Rear Mount	5753 5757	5753D —	• •
P150, P190, PB150, PB190, PC150, PC190 Mono	20-1001	Record/Play Program Record/Play & Cue	Rear Mount	2051 2050		2001 } 2000 } 114
<b>AUDI-CORD</b>		NOTES: *Play-only machines substitute dummy head for record head.				
100,101 Mono		Dummy Head* Play	No Mount	7605 2001	7605D 2001D	
105, 106 Stereo		Dummy Head* Play	No Mount	7605 5701	7605D 5701D	
110, 111 Mono		Record Play	No Mount	2003 2001	2003D 2001D	
115, 116 Stereo		Record Play	No Mount	5703 5701	5703D 5701D	
120, 121 Mono		Record Play	No Mount	2003 2001	2003D 2001D	
125, 126 Stereo		Record Play	No Mount	5703 5701	5703D 5701D	
130, 132, 134, 136 Network Delay		Play	No Mount	2000		